

LIONEL SERVICE MANUAL

TEN-W
PL
3-60
PAGE 3

NO. 2426W - TENDER

TEN-2426 W

Part Number	Location	Unit Price	Min. Quan.	Description
700T-9	G-51	.10	6	Grab Handle
700T-14	G-61	.20		Front Step
2426T-4	C-23	1.00		Frame
2426T-10	G-91	.15	4	Drawbar
2426W-12	B-16	4.50		Body
2625-50	G-46	.05	12	Centering Spring
WS-225	D-32	8.00		Whistle Complete
4 x 3/8"		.02	25	RHST "Z" Coal Pile Screw
4-40 x 3/16"		.02	25	Fil. H. Step Screw
4-40 x 1/4"		.02	25	RH Body Mtg. Screw
6 x 3/16"		.02	25	RHST "Z" Whistle Mtg. Screw

NO. 2466W - TENDER

TEN-2426 W

480-18	G-52	.03	50	Truck Retaining Washer
482-3	P-33	.50	6	Truck Baseplate W/Roller
1666E-II	E-53	.02	25	Cotter Pin
1666T-5	Obselete			Handrail
2020W-6	V-43	2.50		Body
2466T-10	G-46	.15	4	Drawbar
2466W-3	C-23	1.00		Frame
NTCL-1	N-47	1.75		Rear Truck
PT-1	H-21	1.00		Plain Truck
WS-125	K-43	9.00		Whistle Complete
4 x 1/4"		.02	25	RHST "Z" Body Mtg. Screw
6 x 3/16"		.02	25	RHST "Z" Whistle Mtg. Screw

NO. 2671W - TENDER

TEN-2671 W

5C-99	G-62	.05	25	6-22 Hex Nut (Whistle)
6TCLD-1	J-36	1.50		Front Truck
6TCLD-10		2.50		Rear Truck
480-18	G-52	.03	50	Truck Retaining Washer
2046-56	G-44	2.50		Body
2625-50	G-46	.05	12	Centering Spring
2671W-10	C-23	1.50		Frame
2671W-13	G-52	.40		Water Scoop
2671W-20	G-46	.15	4	Drawbar
WS-69	G-62	.02	25	#6 Lockwasher (Relay)

- continued -