

# SERVICE MANUAL

## NO. 400 - RDC PASSENGER DIESEL

&

## NO. 404 - RDC BAGGAGE - MAIL DIESEL

<u>Part Number</u>	<u>Location</u>	<u>Unit Price</u>	<u>Min. Quan.</u>	<u>Description</u>
22-65	J-64	.02	15	Pilot Rivet
50-100	J-80	.10	6	Ornamental Horn
57-300	LC	.20	10	Lamp
61-22	A-61	.05	25	Lamp Contact
100-4	I-31	3.50		Reversing Unit
400-2	J-35	6.00		Cab Assem. (400)
400-6	J-65	.30		Window Strip (400)
400-9	J-65	.10	6	Reflector
400-10	J-65	.30		Lens & Window Piece
400-11	J-65	.10	6	Mtg. Bracket
400-12	J-65	.02	25	Rivet (Mtg. Bracket)
400-22	J-16	1.00		Frame
400-25	J-65	.10	6	Lamp Socket (Center)
400-27	J-65	.05	12	Horn Bracket
400-35	J-65	.15	4	Nameplate (400)
404-2	G-26	6.00		Cab Assem. (404)
480-8	P-62	.15	4	Knuckle
480-16	P-62	.02	50	Knuckle Spring
530-40	I-40	.02	25	Rivet (Reversing Unit Bracket)
622-52	B-72	.10	4	Reversing Unit Bracket
622-121	B-77	pr .60	6 pr	Brush
622-191	B-74	pr .10	6 pr	Brush Spring
671-253	C-57	.10	6	Axle
671M-22	C-75	.05	12	Retaining Washer
671M-23	C-75	.02	25	Thrust Washer (Motor & Truck)
681-121	F-94	.25		Thrust Bearing
2020M-9	E-84	.02	25	Solder Lug
2028-70	J-24	9.50		Motor Truck Complete (Mag.)
2028-71	Sub. 2328-88			Truck Side
2028-85	F-31	2.00		Truck Top Plate Assem.
2028-100	F-24	6.50		Motor Complete
2028-109	A-41	3.50		Armature
2028-171	J-34	6.50		Collector Truck Complete
2321-86	O-61	.50		Coupler Head Assem.
2321-113	O-24	1.50		Brushplate
2321-135	O-61	.05	12	Collector Spring
2321-156	O-61	.25		Coupler Armature Assem.
2321-162	O-61	.05	12	Coupler Centering Spring
2321-164	O-71	.15	12	Coupler Centering Plunger
2328-35	B-38	.40		Battery Cover

- continued -